

Turbidity Water Quality Sensor Module

(Model: ZW-TUR101)

Manual

Version: 1.1

Valid From: 2021-12-16

Zhengzhou Winsen Electronics Technology Co., Ltd

Statement

This manual copyright belongs to Zhengzhou Winsen Electronics Technology Co., LTD. Without the written permission, any part of this manual shall not be copied, translated, stored in database or retrieval system, also can't spread through electronic, copying, record ways.

Thanks for purchasing our product. In order to let customers use it better and reduce the faults caused by misuse, please read the manual carefully and operate it correctly in accordance with the instructions. If users disobey the terms or remove, disassemble, change the components inside of the sensor, we shall not be responsible for the loss.

The specific such as color, appearance, sizes &etc, please in kind prevail.

We are devoting ourselves to products development and technical innovation, so we reserve the right to improve the products without notice. Please confirm it is the valid version before using this manual. At the same time, users' comments on optimized using way are welcome.

Please keep the manual properly, in order to get help if you have questions during the usage in the future.

Zhengzhou Winsen Electronics Technology CO., LTD

_

ZW-TUR101 Turbidity water quality sensor module

Profile

ZW-TUR101 turbidity detection module is a universal module with high precision and low range, which reflects the turbidity of the water by detecting the content of suspended solids in the water.

The module adopts RS485 standard signal output and 4-20mA output, which has the characteristics of high detection accuracy and good stability, and is widely used in the detection of various low-turbidity water environments.



Fig1. Sensor module image

Main application

It is widely used in the turbidity detection of industrial water use, secondary water supply, water treatment and other scenarios

Technical indicators

Measure range	0-20NTU;	Measure accuracy	4% F.S.
	0-100NTU		
Temperature range	0-60℃	Shell material	ABS
Operating voltage	9-30V (DC)	Levels of protection	IP68
Output type	RS485/4-20mA	Pressure tolerance	0-1bar
		range	

The electrode wiring



Tel: 86-371-67169097/67169670 Fax: 86-371-60932988 Email: <u>sales@winsensor.com</u>

Communication protocol

1. General Settings

Baud rate	9600
Data bits	8 bit
Stop bit	1 bit
Check bit	None
Address	1(default)

2.ZW-TUR101 turbidity detection module calibration

Before calibration, write the value of the standard fluid to be calibrated into the corresponding register.

Write the correction value at first point, second point, third point and fourth point before calibration.

- ①If the correction value for the first point is 1.000, the data 0x 3F 80 00 00 is written to the register 0x29, Send instruction: 01 10 00 29 00 02 04 00 00 3F 80 21 8D
- ②If the correction value for the second point is 10.000, the data 0x 41 20 00 00 is written to the register 0x2D

Send instruction: 01 10 00 2D 00 02 04 00 00 41 20 01 A6

 \bigcirc If the correction value for the third point is 20.000, the data 0x 41 A0 00 00 is written to the register 0x 31

Send instruction: 01 10 00 31 00 02 04 00 00 41 A0 01 5F

4 If the value corrected for the fourth point is 30.000, the data 0x 41 F0 00 00 is written to the register 0x 35

Send instruction: 01 10 00 35 00 02 04 00 00 41 F0 00 90

3.Data format

Module	Function	Register		Register		Byte	Write to the storage data a			data a	CRC16	
addresses	code	start		number		number	hexadecimal floating point			point		
		address										
		High	Low	High	Low		С	D	Α	В	Low	High
		Byte	byte	Byte	byte						byte	Byte
01	10	00	29	00	02	04	00	00	3F	80	21	D8

Tel: 86-371-67169097/67169670 Fax: 86-371-60932988 Email: <u>sales@winsensor.com</u>

Note: When writing floating point data, the high and low bytes should be converted, namely hexadecimal 3F 80 00 00, and the high and low bytes transposition 00 00 3F 80 write to the corresponding register.

4. Start the calibration sensor:

Step 1:

Clean and put the sensor into the first point of correction fluid to send instruction 01 03 00 18 00 02 44 0C Read the AD measured value in the register 00 18 , and after the AD measured value is stable, write the current AD value in the register 00 2B ,

For example: the current AD value is 100, send instruction: 01 10 00 28 00 02 04 00 64 00 00 F1 DB Repeat Step 1 to write the AD value of the calibration point to the registers 00 2F, 00 33, and 00 37 to complete the calibration of the sensor.

5.Read the number of floating points:

Send instructions

Module	Function	Register	start	Register number		CRC16	
addresses	code	address					
		High	Low byte	High Low byte		Low byte	High Byte
		Byte		Byte			
01	03	00	01	00	02	95	СВ

Return the value

Module	Function	Byte	Write	to t	the	storage	data a	CRC16	
addresses	code	number	hexadec	hexadecimal floating point					
			С	D		Α	В	Low	High
								byte	Byte
01	10	04	2C	81		40	91	52	E7

Note: 72 37 41 DB is converted to floating point, CDAB is converted to ABCD, that is, 41 DB 72 37 is converted to floating point as 27.4.

Modify device address:

Send instructions

Module Function		Register start address		Register	number	CRC16	
addresses	code	High Byte	Low byte	High Byte	Low byte	High Byte	Low byte
01	06	00	00	00	02	08	ОВ

Return the value

Module	Function	Function Register start address		Register	number	CRC16	
addresses	code	High Byte	Low byte	High Byte	Low byte	High Byte	Low byte
01	06	00	00	00	02	08	ОВ

Note: Change the address of this device from 01 to 02, and write the hexadecimal 00 02 into the register 00 00

Tel: 86-371-67169097/67169670 Fax: 86-371-60932988 Email: <u>sales@winsensor.com</u>

Precautions

- 1. After using the sensor, clean it and put it away; after long-term storage, it needs to be electrified and polarized before use.
- 2. The cable connector must be kept dry and tidy to prevent moisture corrosion;
- 3. When the water is cut off or not in use, the sensor should be taken out and cleaned, wiped dry;
- 4. It is recommended to clean and inspect the sensor every 30 days to ensure the normal operation of the sensor.

Zhengzhou Winsen Electronics Technology Co., Ltd

Add: No.299, Jinsuo Road, National Hi-Tech Zone, Zhengzhou

450001 China

Tel: +86-371-67169097/67169670

Fax: +86-371-60932988

E-mail: sales@winsensor.com

Website: www.winsen-sensor.com